

QUICK START



1. TURNING THE KID'SLEEP CLASSIC ON


- The Kid'Sleep can operate plugged into an outlet, using batteries, or both.
- If you wish to insert batteries, make sure that you insert the batteries before plugging in the Kid'Sleep Classic.** Inserting batteries while connected to power may result in malfunction.
- To insert batteries, open the battery pack using a screwdriver, and place 3 new (AA) batteries.

2. SETTING THE CLOCK AND WAKE UP TIMES

- Press and hold «time» until the numbers on the digital clock start blinking.
- Set hours using «up» and «down».
- Press «time» again to set minutes, using «up» and «down».
- Press «time» again to finish setting the time.
- To set the time at which you would like your child to wake up in the **morning**, repeat steps a. through d. with «Alarm 1». To set the time at which you would like your child to wake up from **naptime**, repeat steps a. through d. with «Alarm 2»

3. BEDTIME

- Make sure to reset the Kid'Sleep by setting the Main Switch to .
- When your child goes to bed, set the Main Switch to . **At that time the rabbit will always light up in the sleeping position.** When it is time to wake up, the light will change to the waking rabbit.
- Upon waking up, you may switch off the light by setting the main switch to in order to save energy.



4. ADDITIONAL FEATURES

- To use the Kid'Sleep as an alarm clock, set the main switch to at bedtime instead of . The transition to the waking rabbit will be accompanied by a birdcall.
- The brightness can be adjusted by setting the Brightness Switch to or .
- The Kid'Sleep can be used as a traditional night-light by setting the Main Switch to and replacing the split display pane on the front side of the device with the single display pane included in the box. The panes can be removed by sliding them counterclockwise and pulling.